

Beam-Plasma Interactions in the Marshall Magnetic Mirror

**Todd Schneider, Jason Vaughn,
M.R. Carruth Jr., David Edwards**
Marshall Space Flight Center
Huntsville, AL 35812



Outline of Presentation



- **Plasma Propulsion**
 - Motivation
 - Existing Devices
- **Marshall Magnetic Mirror**
 - Magnetic Mirrors
 - Description of M3 Device
- **Beam-Plasma Experiment**
 - Experiment Description
 - Plasma Parameters
- **Diagnostics**
- **Initial Data**
- **Future Experiments and Collaborations**



Plasma Propulsion




- **High temperature and density gas (plasma) is ejected at high velocity from a containment device thereby creating thrust.**
 - Require density $> 10^{17} \text{ m}^{-3}$; Require temperature $> 100 \text{ eV}$
- **Magnetic fields are used to contain the plasma and ultimately to form a magnetic nozzle.**
- **Cylindrical magnetic field geometries are a natural choice for propulsion.**
- **Plasma propulsion is expected to yield high Specific Impulse (Isp).**
 - Isp scales with temperature of propellant
- **Demonstration Device is being built within NASA**
 - VASMIR device at JSC is almost at demonstration phase
 - On-orbit requirements have been plotted



Magnetic Mirrors




- Magnetic mirrors are common to most plasma propulsion designs.



Drawing from Lawrence Livermore National Lab Fusion Education Web Site
(<http://education.llnl.gov/lasers/fusion/blue15.html>)



Marshall Magnetic Mirror Layout



April 5, 2001

Advanced Space Propulsion
Workshop



Marshall Magnetic Mirror



April 5, 2001


Advanced Space Propulsion
Workshop



Plot of Magnetic Field Strength in the M3 Device



- **Magnetic field strength as a function of position (Lengthwise)**



Scan Through Length

100 Amps Through Coils
(Resistance = 0.44 ohms)

B-field:

Max. = 989 Gauss

Min. = 655 Gauss


Ratio = 1.5



Plot of Magnetic Field Strength in the M3 Device



- Magnetic field strength as a function of position (Radial)**



Scan Through
Diameter

100 Amps Through Coils
(Resistance = 0.44 ohms)

B-field:

Max. = 657 Gauss



M3 Description and Support Equipment



- **Magnet Coils**
 - Each magnet is composed of 9 individual coils
 - Total number of turns (series) is: 33 turns per coil x 9 Coils x 2 Sets = 594 turns
 - Cylindrical Vacuum Chamber
- **Magnet Power Supply System**
 - Three (3) DC power supplies; 310 amps, 32 volts – series operation
 - Maximum Magnetic Field on axis is: 1,000 Gauss
- **Microwave Power Supply System**
 - 2 kW CW source, 2.45 GHz
- **Electron Beam System**
 - Hollow Cathode System (EPL Model HCPEE 500)
 - 50 amps continuous rating; 100 amps for 30 secs
 - Capacitor Bank supply will allow 400-500 amps for 200 milliseconds
- **Gas Feed System**
 - Use Argon, Xenon, and Hydrogen gas
 - Mass flow controller: 0.5 sccm to 10 sccm



Beam-Plasma Experiment



- **Conduct an experimental study of the interaction of an electron beam with a plasma.**
- **Determine feasibility of using an electron beam to increase plasma density and temperature for future plasma propulsion devices**
- **Initial plasma density limited by cut-off density**
 - For 2.45 GHz, Cut-off density = $1 \times 10^{11} \text{ cm}^{-3}$
- **Optimize the power coupling between the electron beam and plasma by varying several parameters.**
 - Neutral gas type and density
 - Magnetic field strength and configuration (trim coils)
 - Microwave power input to plasma
 - Beam energy and current
- **Compare results with theory and modeling.**
 - Plasma wave excitation/instabilities
 - Use beam-plasma computer codes (existing)



Diagnostics



- **Langmuir Probes**
 - Scan inside magnetic mirror and downstream
 - Look at relative changes in electron temperature and plasma density with and without beam injection
- **Mach Probes**
 - Measure exit velocities outside of mirror
- **Pearson Coils**
 - Determine electron beam pulse parameters
- **Microwave Interferometer(s)**
 - Measure plasma density with and without e-beam injection
 - Two interferometers existing:
 - 10 GHz (X-band) Interferometer
 - 60 GHz (V-band) Interferometer
- **Data Acquisition**
 - Digital Oscilloscopes (8 channels) 400 MHz
 - PXI Modular DAQ System with embedded controller
 - 4 oscilloscope channels (100 MHz)
 - Directly integrated into Labview System/PC



Future Work



- **Increase electron beam current by utilizing existing capacitor bank power supply**
- **Utilize new 2000 amp power supply to operate at higher magnetic fields (perhaps 2 kgauss).**
- **Have partnered with Oak Ridge National Lab to increase diagnostic capabilities (improvements to microwave interferometers).**
- **Will be testing Submicron Retarding Field Energy Analyzer (also in partnership with Oak Ridge).**
- **Investigate the use of a helicon plasma source to achieve high initial plasma density**